

8 7 6 5 4 3 2 1

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF INTELLECT. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF INTELLECT IS PROHIBITED.

D

Straight Thru Hole Installation

If your application allows access to the bottom of the board, drill 5/16" thru holes and secure the washers and nuts at the bottom of the board.

C

Counterbore Installation

If your application does NOT allow for long bolts to drop through the bottom of board, you will need to use a 1/2" auger/spade drill bit to counterbore a recess for the washer and nut. NOTE: you may need to remove the board from the bench, apply the clip, then re-install the board.

B

A

INTELLECT
SAN DIEGO, CALIFORNIA, U.S.A.

**FR012 BC
Installation**

SIZE A	DWG. NO.	REV.
SCALE	CAD FILE:	SHEET OF

8 7 6 5 4 3 2 1